

Kemlan Coupe Wall Penetration - Installation Photos

To be used as a guide only—the installation manual must be referred to in the first instance



Timber Frame Out



Hebel panels and floor protector for both free-standing and inbuilt sides



Fireplace positioned and ceiling flue kit installed from ceiling level up—drop box installed.

The firebox is removed whilst the hebel is plastered, painted and floor protection finished in tiles, stone or similar



Flush mounted side
Timber Frame Out with
Hebel AAC panel margin
installed



Freestanding side
Showing Ceiling Flue
Drop Box
Timber Frame Out with
Hebel AAC panel margin
installed

Fire installation is completed - post decorating

